

# Section 1

1

Tech Trays

## Tech Trays & Value Packs

- Contains the fastest moving parts installers use to get the job done
- Have the parts there when you need them – comprehensive coverage of the most common items
- Stock hardware the smart way – lower cost hardware placed in trays for higher profits
- Convenience and portability at an affordable price
- Making storage easy by having only two plastic size trays
- Makes reordering effortless by using the convenient Dorman reorder form
- Eliminate wasted bay time and money waiting for the part – potential bay time saved – an average of \$720 per tray!
- Specialty trays available for specialty installers – body shops, oil & lube, transmission, tire & wheel

**SECTION #** Additional Dorman boxed product located in the section number indicated in this catalog.

**SECTION MM** Additional Dorman boxed product location in the Motormite Catalog (MM24010).

**SECTION HP** Additional Dorman boxed product located in the Dorman Hard Parts Catalog (DHP24011).

**SECTION 22** Additional Tites! product located in Section 22 of this catalog.















**It's Friday afternoon at 5:00. Do you have the parts to finish the job?**

### Part # 030-136

### COTTER PINS TECH TRAY

SECTION 4

- 12 SKUs, 390 pieces • Tray measures 13-1/8"W x 2-5/16"H x 9"D

<b>800-110</b> 1/16" x 1"  Reorder Qty. 375 Assort. Qty. 50	<b>800-215</b> 3/32" x 1-1/2"  Reorder Qty. 200 Assort. Qty. 50	<b>800-410</b> 1/8" x 1"  Reorder Qty. 200 Assort. Qty. 50	<b>800-415</b> 1/8" x 1-1/2"  Reorder Qty. 140 Assort. Qty. 20	<b>800-420</b> 1/8" x 2"  Reorder Qty. 120 Assort. Qty. 50	<b>800-520</b> 5/32" x 2"  Reorder Qty. 70 Assort. Qty. 25
<b>800-210</b> 3/32" x 1"  Reorder Qty. 300 Assort. Qty. 20	<b>800-220</b> 3/32" x 2"  Reorder Qty. 180 Assort. Qty. 25	<b>800-412</b> 1/8" x 1-1/4"  Reorder Qty. 155 Assort. Qty. 25	<b>800-417</b> 1/8" x 1-3/4"  Reorder Qty. 130 Assort. Qty. 25	<b>800-515</b> 5/32" x 1-1/2"  Reorder Qty. 100 Assort. Qty. 25	<b>800-620</b> 3/16" x 2"  Reorder Qty. 65 Assort. Qty. 25

# Tech Trays













## Part # 030-180

## CABIN AIR FILTER HARDWARE TECH TRAY

• 13 SKUs, 105 pieces • Tray measures 11"W X 1-3/4"H X 6-3/4"D

SECTION  
20

1  
Tech Trays

<b>700-700</b> Ford Taurus/Sable 4mm Screw  REORDER QTY: 15 ASSORTMENT QTY: 10	<b>700-701</b> Ford Contour/Mystique Self-Tapping Screw  REORDER QTY: 10 ASSORTMENT QTY: 5	<b>700-702</b> Ford Contour/Mystique Black Plastic Cap  REORDER QTY: 15 ASSORTMENT QTY: 10	<b>700-703</b> Ford Taurus/Sable Retainer Clip  REORDER QTY: 15 ASSORTMENT QTY: 10	<b>700-704</b> Ford Taurus/Sable Push-On Clip  REORDER QTY: 15 ASSORTMENT QTY: 10	<b>700-705</b> Ford Taurus/Sable Plastic Screw  REORDER QTY: 15 ASSORTMENT QTY: 10
<b>700-706</b> General Motors Screw Rivet  REORDER QTY: 15 ASSORTMENT QTY: 10		<b>700-707</b> General Motors Screw Rivet  REORDER QTY: 15 ASSORTMENT QTY: 10	<b>700-708</b> General Motors Screw Cap  REORDER QTY: 10 ASSORTMENT QTY: 5		<b>700-709</b> Ford Contour/Mystique Screw-In Clip  REORDER QTY: 10 ASSORTMENT QTY: 5
<b>700-710</b> Lincoln Continental Retainer Screw  REORDER QTY: 15 ASSORTMENT QTY: 10	<b>700-711</b> Oldsmobile Alero/Chevy Malibu Cowl Retainer  REORDER QTY: 15 ASSORTMENT QTY: 5		<b>700-712</b> Lincoln LS/Ford T-Bird Cowl Retainer  REORDER QTY: 15 ASSORTMENT QTY: 5		

















## Part # 030-200

## DIESEL SERVICE PARTS

NEW!

SECTION  
MM

• 16 SKUs, 122 pieces and 4 kits • Tray measures 13" x 8-13/16" x 2-3/16"













<b>099-424</b> OE 9722893 GM Trucks 6.6L 2005-01  REORDER QTY: 25 ASST. QTY: 5	<b>099-425</b> OE 97251046 GM Trucks 6.6L 2005-01  REORDER QTY: 25 ASST. QTY: 5	<b>099-426</b> OE 97251047 GM Trucks 6.6L 2005-01  REORDER QTY: 25 ASST. QTY: 5	<b>099-427</b> OE 94051259 GM Trucks 6.6L 2005-01  REORDER QTY: 25 ASST. QTY: 10
<b>099-428</b> OE 3C3Z-9A375-AA Ford 6.0L 2006-03  REORDER QTY: 20 ASST. QTY: 5	<b>099-429</b> OE F4TZ-9A375A Ford 7.3L 1998-94  REORDER QTY: 20 ASST. QTY: 5	<b>099-430</b> OE F4TZ-6769-C Ford 7.3L & 6.0L 2004-99  REORDER QTY: 20 ASST. QTY: 5	<b>099-431</b> OE F4TZ-6N653-B Ford 7.3L 1997-94  REORDER QTY: 20 ASST. QTY: 5
<b>099-432</b> OE F4TZ-6N653-A Ford 7.3L 1997-94  REORDER QTY: 20 ASST. QTY: 5	<b>099-433</b> OE F4TZ-9C387-A Ford 7.3L 1998-94  REORDER QTY: 20 ASST. QTY: 5	<b>099-434</b> OE E6TZ-9229-AB Ford 6.9L & 7.3L (Non-Turbo) 1993-83  REORDER QTY: 20 ASST. QTY: 10	<b>099-435</b> OE XC3Z-9229-AB Ford 7.3L 2003-99  REORDER QTY: 20 ASST. QTY: 2 Kits
<b>099-436</b> OE F4TZ-6769-A Ford 7.3L 2004-99  REORDER QTY: 20 ASST. QTY: 5	<b>099-437</b> OE 501655AB Various Chrysler 5.9L  REORDER QTY: 20 ASST. QTY: 5	<b>099-438</b> OE 4429824 Various Chrysler 5.9L  REORDER QTY: 20 ASST. QTY: 5	<b>099-439</b> OE 3C3Z-9229-AA Ford 6.0L 2006-03  REORDER QTY: 20 ASST. QTY: 2 Kits

New Product Hotline - 800-336-3575

Section 1













**Part # 030-201****CAMSHAFT SEALS****NEW!**SECTION  
MM

• 12 SKUs, 24 pieces • Tray measures 13" x 8-13/16" x 2-3/16"

<b>099-440</b> OE MD372536, MD133317 <i>Various Chrysler</i> 	<b>099-441</b> OE 4792318 <i>Chrysler 3.5L 2006-98</i> 	<b>099-442</b> OE MD152603 <i>Dodge 3.0L 1995-91</i> 	<b>099-443</b> OE 90311-42027 <i>Various Toyota 3.0L</i> 	<b>099-444</b> OE 90311-35022 <i>Various Toyota Corolla</i> 	<b>099-445</b> OE 90080-31023 <i>Various Toyota Camry</i> 
<b>099-446</b> OE 90311-40022 <i>Various Toyota Avalon</i> 	<b>099-447</b> OE 91233-PT0-003 <i>Various Honda Accord - Counterbalance</i> 	<b>099-448</b> Retainer <i>Various Honda Accord</i> 	<b>099-449</b> OE 91213-PT0-003 <i>Various Honda Accord - Camshaft</i> 	<b>099-450</b> OE 10342-16A06 <i>Various Nissan</i> 	<b>099-451</b> OE 4777086 <i>Dodge Neon 2.0L 2006-95</i> 

**Part # 030-202****WINDOW GUIDES****NEW!**SECTION  
MM

• 12 SKUs, 48 pieces • Tray measures 13" x 8-13/16" x 2-3/16"

<b>700-886</b> Front & Rear <i>Chevrolet/GMC Truck: S/T Series Blazer, Jimmy, Pickups, Sonoma 1994-82; Oldsmobile: Bravada 1994-91</i> 	<b>700-887</b> Rear <i>Buick: Century, Electra, LeSabre, Skylark; Cadillac: Deville, Fleetwood Brougham; Chevrolet: Caprice, Celebrity, Citation; Impala; Chevrolet/GMC Truck: S/T Series Blazer, Jimmy, Pickups; Oldsmobile: Ciera, Delta 88, Omega, 98 Regency; Pontiac: 6000, Phoenix 1994-80</i> 	<b>700-871</b> Front <i>Buick: Electra, LeSabre, Park Ave; Cadillac: Deville, Fleetwood; Oldsmobile: 88 Delta Royale, 98 Regency; Pontiac: Bonneville 1993-85</i> 	<b>700-888</b> Rear <i>Buick: Electra, LeSabre, Park Ave; Cadillac: Deville, Fleetwood; Oldsmobile: 88 Delta Royale, 98 Regency; Pontiac: Bonneville 1993-85</i> 	<b>700-889</b> Rear <i>Chevrolet: Celebrity; Buick: Century; Oldsmobile: Ciera; Pontiac: 6000 1996-89</i> 	<b>700-874</b> Rear <i>Buick: Electra, LeSabre; Cadillac: Seville; Chevrolet: Caprice; Oldsmobile: Delta 88, 98 Regency; Pontiac: Bonneville 1992-80</i> 
<b>700-890</b> Rear <i>Chevrolet: Corsica 1994-87</i> 	<b>700-891</b> Rear <i>Dodge: Dakota 1994-87</i> 	<b>700-892</b> Rear <i>Buick: Skyhawk; Cadillac: Cimarron; Chevrolet: Cavalier; Oldsmobile: Firenza; Pontiac: J2000, Sunbird 1994-82</i> 	<b>700-893</b> Rear <i>Chevrolet Corsica 1996-87</i> 	<b>700-894</b> Left <i>Buick: Electra Park Ave, LeSabre, Somerset, Skylark; Cadillac: Fleetwood, Deville; Oldsmobile: 88, 98 Regency, Calais, Delta Royale; Pontiac: Bonneville, Grand Am 1996-85</i> 	<b>700-895</b> Right <i>Buick: Electra Park Ave, LeSabre, Somerset, Skylark; Cadillac: Fleetwood, Deville; Oldsmobile: 88, 98 Regency, Calais, Delta Royale; Pontiac: Bonneville, Grand Am 1996-85</i> 













**Part # 030-203****WIPER LINKAGE BUSHINGS****NEW!**SECTION  
MM

• 6 SKUs, 24 pieces • Tray measures 8-1/4" x 4-1/4" x 1-11/32"

<b>118-301</b> <i>Chrysler</i> 1974 + Up	<b>118-302</b> <i>Toyota Avalon,</i> <i>Camry 2001-97;</i> <i>Corolla 2002-98 -</i> 4 needed.	<b>118-303</b> <i>Toyota Avalon,</i> <i>Camry 2001-97;</i> <i>Corolla 2002-98 -</i> 1 needed.	<b>118-304</b> <i>Nissan Altima</i> 2001-88	<b>118-305</b> <i>GM Trucks</i> 2005-88	<b>118-306</b> <i>Jeep Cherokee</i> 2000-93				
									
Reorder Qty. 5	Assortment Qty. 4	Reorder Qty. 5	Assortment Qty. 4	Reorder Qty. 5	Assortment Qty. 4	Reorder Qty. 5	Assortment Qty. 4	Reorder Qty. 5	Assortment Qty. 4

**Part # 030-204****SPARK PLUG WIRE RETAINERS****NEW!**SECTION  
MM

• 12 SKUs, 48 pieces • Tray measures 13" x 8-13/16" x 2-3/16"

<b>647-100</b> Various GM 8 Cyl. Cars & Trucks	<b>647-101</b> Various GM 8 Cyl. Cars & Trucks	<b>647-102</b> Universal - Locking 6,7,8mm, four wire.	<b>647-103</b> GM - Locking 7mm. Four wire, bracket style.	<b>647-104</b> Universal - 6,7,8 mm. Designed so retainer slots can be separated.	<b>647-105</b> GM - Locking 7mm. Two wire, bracket style.
					
REORDER QTY: 10	ASST. QTY: 4	REORDER QTY: 10	ASST. QTY: 4	REORDER QTY: 10	ASST. QTY: 4
<b>647-106</b> Ford - Locking 7mm. Three wire, stud slotted.	<b>647-107</b> Ford - Locking 7mm. Two wire, stud slotted.	<b>647-108</b> Ford Explorer 2001-91, Ranger 2003-91, Aerostar 1997-91	<b>647-109</b> Ford Explorer 2001-91, Ranger 2003-91, Aerostar 1997-91	<b>647-110</b> Ford Explorer 2001-91, Ranger 2003-91, Aerostar 1997-91	<b>647-111</b> Ford Aerostar 1997-91, Explorer 2001-91, Ranger 2003-91
					
REORDER QTY: 10	ASST. QTY: 4	REORDER QTY: 10	ASST. QTY: 4	REORDER QTY: 10	ASST. QTY: 4



**Part # 030-205****HEATER HOSE CONNECTORS****NEW!**SECTION  
MM

• 12 SKUs, 36 pieces • Tray measures 13" x 8-13/16" x 2-3/16"

<b>500-010</b> 3/4" x 3/4" 	<b>500-011</b> 3/4" x 5/8" 	<b>500-012</b> 5/8" x 5/8" 	<b>500-013</b> 1/2" x 5/8" 	<b>500-014</b> 1/2" x 1/2" 	<b>500-018</b> 1/2" x 3/8" 
REORDER QTY: 3	ASST. QTY: 3	REORDER QTY: 3	ASST. QTY: 3	REORDER QTY: 3	ASST. QTY: 3
<b>500-019</b> 3/8" x 3/8" 	<b>500-024</b> 1/4" x 1/4" 	<b>500-032</b> Elbow 5/8" x 3/8" x 5/8" 	<b>500-033</b> Elbow 5/8" x 5/8" 	<b>500-034</b> 3/8" Hose x 1/4" NPT x 1" Long 	<b>500-048</b> 5/8" Hose x 1/4" UNS x 2" Long; GM 3.8L 1995-90 
REORDER QTY: 3	ASST. QTY: 3	REORDER QTY: 3	ASST. QTY: 3	REORDER QTY: 3	ASST. QTY: 3













**Part # 030-206****EXHAUST HARDWARE****NEW!**SECTION  
MM

• 12 SKUs, 24 kits • Tray measures 13" x 8-13/16" x 2-3/16"

<b>675-216</b> Chevrolet/GMC Truck 1996-88 M10-1.5 x 77mm 	<b>675-210</b> GM C,K,R,V Series 1991-83 3/8"-16 x 3.5" 	<b>675-212</b> Chrysler 1999-88 M8-1.25 x 3" 	<b>675-203</b> GM 1996-82 M10-1.5 x 72mm 	<b>675-217</b> GM 1998-95 5.0L & 5.7L 3/8"-16 x 2-1/4" 	<b>675-218</b> GM 2.5L & Toyota 1997-88, M10-1.5 
REORDER QTY: 3 Kits	ASST. QTY: 3 Kits	REORDER QTY: 3 Kits	ASST. QTY: 3 Kits	REORDER QTY: 3 Kits	ASST. QTY: 3 Kits
<b>675-207</b> GM 1990-71 3/8"-16 x 1-3/4" 	<b>675-209</b> GM C,K,R,V Series 1987-83 3/8"-16 x 4.5" 	<b>675-219</b> GM 1987-79 3/8"-16 x 2-13/16" 	<b>675-208</b> GM 1995-72 M10-1.5 x 102mm 	<b>675-220</b> GM 1996-86 M10-1.5 	<b>675-221</b> Toyota RAV4 and Celica 2003-95 M10-1.25 x 67mm 
REORDER QTY: 3 Kits	ASST. QTY: 3 Kits	REORDER QTY: 3 Kits	ASST. QTY: 3 Kits	REORDER QTY: 3 Kits	ASST. QTY: 3 Kits














**Part # 030-208****DOOR HINGE PINS****NEW!**SECTION  
MM

• 12 SKUs, 24 kits • Tray measures 13" x 8-13/16" x 2-3/16"

<b>703-263</b> GM S10 Blazer, Jimmy, Pickups 1994-82; Safari, Astro 1998-85  REORDER QTY: 3 Kits ASST. QTY: 2 Kits	<b>703-264</b> GM Cars & Trucks 1998-60, Sizes: .344" x .490" x .370" (bushing), .344" x .420" x .305" (bushing), .342" x 4.167" (pin)  REORDER QTY: 2 Kits ASST. QTY: 2 Kits	<b>703-265</b> GM S10 Pickups, Blazer, Bravada, Jimmy, Sonoma 2003-94  REORDER QTY: 2 Kits ASST. QTY: 2 Kits	<b>703-266</b> GM Cars 1998-80, .345" x .420" x .305" (bushing), .342" x 3.863" (pin)  REORDER QTY: 2 Kits ASST. QTY: 2 Kits	<b>703-267</b> GM C&K Series Pickups 2004-99  REORDER QTY: 3 Kits ASST. QTY: 2 Kits	<b>703-268</b> GM Full-Size Vans - Express, Savana 2004-96  REORDER QTY: 2 Kits ASST. QTY: 2 Kits
<b>703-269</b> Ford F150-350 Pickups 1998-80, Sizes: .345" x .480" x .295" (bushing), .342" x 3.57" (pin)  REORDER QTY: 3 Kits ASST. QTY: 2 Kits	<b>703-270</b> Ford Cars & Trucks: F58Z-1622800A, 1L5Z-1622810-AA, F4SX-6322800-B  REORDER QTY: 2 Kits ASST. QTY: 2 Kits	<b>703-271</b> Ford Capri, Mustang 1998-79  REORDER QTY: 2 Kits ASST. QTY: 2 Kits	<b>703-272</b> Dodge Truck B Series Vans, D/W Series Pickups, Ramcharger 1997-84, Sizes: .376" x .495" x .250" (bushing), .374" x 2.495" (pin), .374" x 3.590" (pin)  REORDER QTY: 2 Kits ASST. QTY: 2 Kits	<b>703-273</b> Dodge Ram Trucks 2002-94, Sizes: .376" x .495" x .250" (bushing), .345" x .430" x .300" (bushing), .373" x 3.25" (pin), .342" x 2.79" (pin)  REORDER QTY: 2 Kits ASST. QTY: 2 Kits	<b>703-274</b> GM/Ford/Chrysler Cars & Trucks 1998-60, Sizes: (ID x OD x Height) .344" x .490" x .370", .344" x .490" x .375", .345" x .420" x .305", .376" x .495" x .250"  REORDER QTY: 2 Kits ASST. QTY: 2 Kits

**Part # 030-209****DOOR LOCK ROD CLIPS****NEW!**SECTION  
MM

• 16 SKUs, 80 pieces • Tray measures 13" x 8-13/16" x 2-3/16"

<b>703-235</b> OE 16607593 GM  REORDER QTY: 15 ASST. QTY: 5	<b>703-236</b> OE 16627328 GM  REORDER QTY: 15 ASST. QTY: 5	<b>703-237</b> Ford  REORDER QTY: 15 ASST. QTY: 5	<b>703-238</b> GM  REORDER QTY: 15 ASST. QTY: 5
<b>703-239</b> GM  REORDER QTY: 15 ASST. QTY: 5	<b>703-240</b> OE 16675980, F85Z-1521952 BA Ford  REORDER QTY: 15 ASST. QTY: 5	<b>703-241</b> OE YL3Z-1521971 AB GM, Ford  REORDER QTY: 15 ASST. QTY: 5	<b>703-242</b> OE E83Z-5421952 B Ford  REORDER QTY: 15 ASST. QTY: 5
<b>703-243</b> OE 80534-4Z300 Nissan  REORDER QTY: 15 ASST. QTY: 5	<b>703-244</b> OE 80534-50J00 Nissan  REORDER QTY: 15 ASST. QTY: 5	<b>703-245</b> OE 80534-0P000 Nissan  REORDER QTY: 15 ASST. QTY: 5	<b>703-246</b> OE 69759-14050 Toyota  REORDER QTY: 15 ASST. QTY: 5
<b>703-247</b> OE 69293-12040 Toyota  REORDER QTY: 15 ASST. QTY: 5	<b>703-248</b> OE 80532-89900 Nissan/Honda  REORDER QTY: 15 ASST. QTY: 5	<b>703-249</b> OE 80533-AA100 Nissan/Honda  REORDER QTY: 15 ASST. QTY: 5	<b>703-250</b> OE 80532-01R00 Nissan/Honda  REORDER QTY: 15 ASST. QTY: 5